



Motor

		LL06	LL10 (A) and (C)	LL10 (D)	LT20 (A) and (C)	LT20 (D)	LT40 (A) and (C)	LT40 (D)	LTC40	LTC300/LTC450	LS15 (B) and (D)	LR80 (A)	LR80 (B) and LR50 (D)	LR17 (A)	LR23 (A/C)	LR23 (A/C) encoder	LR23 (D)
PMD101	Motor Cable	CK6292	CK6261	CA	CK6274	CK6281	CK6261	CK6281	CA	(only to PMD101 HC)	CA	CK6261	CA	CK6255	CK6261	-	CA
	Sensor Cable	CK6293	-	-	-	-	-	-	-	-	-	-	-		-	-	-
PMD301	Motor Cable	CK6292	CK6261	CA	CK6274	CA	CK6261	CA	CA	CA	CA	CK6261	CA	CK6256	CK6261	Attached cable, specific for driver (Exx)	CA
	Sensor Cable (Encoder)	CK6295	-	-	-	-	-	-	-	-	-	-	-		-		-
PMD401	Motor Cable	CK6292	CK6261	CA	CK6274	CA	CK6261	CA	CA	CA	CA	CK6261	CA	CK6254	CK6261	Attached cable, specific for driver (Fxx)	CA
	Sensor Cable (Encoder)	CK6293	-	-	-	-	-	-	-	-	-	-	-		-		-
PMD206	Motor Cable	-	CK6263	CK6282	CK6273	CK6282	CK6263	CK6282	CK6282	CK6282	CK6282	CK6282	CK6263	-	-	-	CK6282
	Sensor Cable (Encoder)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
DMC-30019	Motor Cable	CK6292	CK6261	CA	CK6274	CA	CK6261	CA	CA	CA	CA	CA	CA	-	CK6261	Attached cable, specific for driver (Gxx)	CA
	Sensor Cable (Encoder)	CK6296	-	-	-	-	-	-	-	-	-	-	-		-		-
PMCM31	Motor Cable	CK6292	CK6261	CA	CK6274	CK6281	CK6261	CK6281	CA	CA	CA	CK6261	CA	-	CK6261	-	CA
	Sensor Cable (Encoder)	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

CA= Cable attached